

HA3 HOST® Applicator Parts List

Code No.	Part No.	Description
1	L8003	Handgrip
2	L8000	Handle Assembly
3	L8004	Crossbar Weldment
4	H1021	End Cap (3 required)
5	L8008	Hole Cover Assembly (3 required)
6	L8017	Applicator Drum
7	L8020	Axle Shaft
8	L8013	Fill Port Cover Assembly <i>(Includes Code Nos. 15, 16, 17, 18, 20 & 21)</i>
9	L8012	Screw Knob (6 required)
10	L8026	Screw $\frac{1}{4}$ -20 x $1\frac{1}{2}$ " (2 required)
11	L8027	Screw $\frac{1}{4}$ -20 x $1\frac{1}{7}$ " (6 required)
12	L8028	Spacer Bar
13	X120	O-Ring (2 required)
14	L8032	Screw (2 required)
15	F2519A	Retainer Washer (2 required)
16	W529	Washer (2 required)
17	L8030	Screw Knob (2 required)
18	L8031	Vinyl Cap (2 required)
19	L8033	Axle Shaft-Short
20	L5003	Washer (4 required)
21	L8016	Fill Port Cover Gasket